

Quick Start Guide



ProCapture-T & ProRF-T
+
ZKBioSecurity 3.0

CONTENT

Safety Precautions.....	2
On Using Face Recognition Device.....	3
Device Overview.....	5
Product Dimensions & Installation.....	7
Power Connection.....	8
Ethernet Connection.....	9
RS485 Connection.....	10
Lock Relay Connection.....	11
Wiegand Output Connection.....	13
Standalone Installation.....	14
Device Operation.....	15



**ZKBioSecurity
Software
Installation and
Setup starts at
Page 18**

Safety Precautions

The following precautions are to keep users safe and prevent any damage. Please read carefully before installation.



Do not install the device in a place subject to direct sunlight, humidity, dust or soot.



Do not place a magnet near the product. Magnetic objects such as magnets, CRTs, TVs, monitors or speakers may damage the device.



Do not place the device next to heating equipment.



Be careful not to let liquid like water, drinks or chemicals leak inside the device.



Do not let children touch the device without supervision.



Do not drop or damage the device.



Do not disassemble, repair or alter the device.



Do not use the device for any other purpose than specified.




Clean the device often to remove dust on it. In cleaning, do not splash water on the device but clean it with a smooth cloth or towel.

Contact your supplier in case of a problem.


On Using Face Recognition Device

1. Recommended Standing Position




For user heights between 1.5m to 1.8m, it is recommended to install the device at 1.15m above ground (may be modified according to user average height).

a. Recommended Registration and Verification Position




During registration and verification procedures, the position of device should not be changed to prevent deduction in verification preciseness. If it is necessary to move the device, its vertical height should not be changed.

b. Factors Affecting the Preciseness of Verification




Non-identical registration and verification gestures




Non-identical registration and verification height

On Using Face Recognition Device



Non-identical registration and verification distances from device



Non-identical registration and verification distances from device

2. Registration

- During registration, it is required to adjust your upper body to fit your eyes into the green frame on the screen.
- During verification, it is required to show your face in the center of the screen and fit your face into the green frame in the screen.




Device Overview


★ Not all products have fingerprint or card function.

ProCapture-T



ProRF-T



Left side & bottom view is common for both the devices




Device Overview




Product Dimensions & Installation

Product Dimensions




Mounting the Device on the Wall




- 1 Fix the back plate onto the wall using wall mounting screws.

Note: We recommend drilling the mounting plate screws into solid wood (i.e. stud/beam). If a stud/beam cannot be found, use supplied drywall plastic anchors.




- 2 Insert the device to back plate.




- 3 Use security screws to fasten the device to back plate.

Power Connection

Without UPS



With UPS (Optional)




Recommended Power Supply

- 12V±10%, at least 500mA
- To share the power with other devices, use a power supply with higher current ratings.

Ethernet Connection

LAN Connection




RS485 Connection

RS485 Fingerprint Reader Connection

DESCRIPTION	WIRE
BEEP	Purple
GLED	Gray
RLED	Blue
IWD1	Green
IWD0	White
GND	Black
+12V	Red


✗ Do not use

PIN	DESCRIPTION	WIRE
1	485B	Yellow
2	485A	Blue
3	GND	Black
4	TXD	Purple
5	RXD	Gray
6	GND	Black
7	WD1	White
8	WD0	Green




Dip Settings

1. There are six DIP switches on the back of RS485 fingerprint reader, switches 1-4 are for RS485 address, switch 5 is reserved, switch 6 is for reducing noise on long RS485 cable.
2. If RS485 fingerprint reader is powered from the terminal, the length of wire should be less than 100 meters or 330 ft.
3. If the cable length is more than 200 meters or 600 ft, the number 6 switch should be ON as below.




← Distance: More than 200 meters →



Lock Relay Connection

Device Not Sharing Power with the Lock




Notes:

1. The system supports **NO LOCK** and **NC LOCK**. For example the **NO LOCK** (normally opened at power on) is connected with 'NO1' and 'COM1' terminals, and the **NC LOCK** (normally closed at power on) is connected with 'NC1' and 'COM1' terminals.
2. When electrical lock is connected to the Access Control System, you must parallel one FR107 diode (equipped in the package) to prevent the self-inductance EMF from affecting the system.


⚠ Do not reverse the polarities.

Lock Relay Connection


Device Sharing Power with the Lock




Wiegand Output Connection



✗ Do not use





Standalone Installation





Device Operation

Date/Time Settings





Press icon to enter the Main Menu > System > Date Time to set date and time.

Adding User



Press icon to enter the Main Menu > User Mgt. > New User to enter the New User adding interface. Settings include entering user ID, user role, choosing user role (Super Admin / Normal User), registering fingerprint ★ / badge number ★ / password, taking user photo ★, and setting access control role.

Ethernet Settings



Press icon to enter the Main Menu > Comm. > Ethernet.

The parameters below are the system default values. Please adjust them according to the actual network.

IP Address: 192.168.1.201

Subnet Mask: 255.255.255.0

Gateway: 0.0.0.0

DNS: 0.0.0.0

TCP COMM. Port: 4370



DHCP: Dynamic Host Configuration Protocol, which dynamically allocate IP addresses for clients via server. If DHCP is enabled, IP cannot be set manually.

Display in Status Bar: To set whether to display the network icon on the status bar of initial interface.

★ Not all products have this function, the real product shall prevail.

Device Operation

ADMS Settings



Press icon to enter the Main Menu > Comm. > ADMS, to set the parameters which are used for connecting with the ADMS server.

When the Webserver is connected successfully, the initial interface will display the logo.



Server Address: Enter IP address of the ADMS server (namely, the IP address of server where the software is installed).

Server Port: Enter the port number used by the ADMS server.

Enable Proxy Server: Method of enabling proxy. To enable proxy, please set the IP address and port number of the proxy server. Entering proxy IP and server address will be the same.

Note: To connect the device to ZKBioSecurity software, Ethernet and ADMS options must be set correctly.

Access Control Settings



Press icon to enter the Main Menu, press and to select Access Control.

To gain access, the registered user must meet the following conditions:

1. User's access time must fall within either user's personal time zone or group time zone.
2. User's group must be in the access combo (when there are other groups in the same access combo, verification of members of those groups are also required to unlock the door).

Access Control Options: To set parameters of the lock and other related devices.

Time Rule Setting: To set a maximum of 50 time rules. Each time rule consists of 10 spaces (7 spaces for one week and 3 holiday spaces), each space consists of 3 time periods.

Holidays: To set dates of holiday and the access control time zone for that holiday.


Combined Verification: To set access control combinations. A combination consists of a maximum of 5 access control groups.

Anti-Passback Setup: To prevent passing back which causes risks to security. Once this function is enabled, entry and exit records must be matched in order to open door. In Anti-Passback, Out Anti-Passback and In/Out Anti-Passback functions are available.

Device Operation

Access Control Combination Settings

E.g. : Add an access control combination which requires 2 person's verification from both Access Control Group 1 (set in User Management) and Access Control Group 2.



1. In “Access Control” interface, press ∇ to select “Combined Verification”; then press \rightarrow to enter the “Combined Verification” list. Click the desired combination and press \rightarrow to enter the modification interface (as shown in figure 2).

2. Click \wedge or ∇ to change the number, click $<$ or $>$ to switch editing box, set the user group number, and click \rightarrow to save and return to “Combined Verification” list (as shown in figure 3).

Note:

- A single access control combination can consist of a maximum of 5 access control groups (in order to open door, verification of all 5 users is required).
- If the combination is set as shown in figure 3, a user from access control group 2 must obtain verification of 2 users from access control group 1 in order to open door.
- Set all access control group number to zero to reset access control combination.

Troubleshooting

- Fingerprint cannot be read or it takes too long ?
 - \Rightarrow Check whether a finger or fingerprint sensor is stained with sweat, water or dust.
 - \Rightarrow Retry after wiping off finger and fingerprint sensor with dry paper tissue or a mildly wet cloth.
 - \Rightarrow If a fingerprint is too dry, blow on the finger and retry.
- “Invalid time zone” is displayed after verification?
 - \Rightarrow Contact Administrator to check if the user has the privilege to gain access within that time zone.
- The Tamper Alarm rings?
 - \Rightarrow Check whether the user privilege is set correctly.
 - \Rightarrow Check whether the lock wiring is correct.
 - \Rightarrow Check whether anti-passback mode is in use. In anti-passback mode, only the person who has entered through that door can exit.
- The Tamper Alarm rings?
 - \Rightarrow To cancel the triggered alarm mode, carefully check whether the device and back plate are securely connected to each other, and reinstall the device properly if necessary.
- How to cancel alarms?
 - \Rightarrow Verify a registered user.

ZKBioSecurity 3.0

It is recommended to install software version 3.0.3.0 or above




Installation & Setup

Downloading.....	19
Installation.....	20
Adding Device.....	22
Creating a Time Zone.....	24
Creating an Access Level.....	25
Enrolling Personnel.....	26
Wiegand Format.....	28
Add & Delete Personnel to Access Level.....	29
Real -Time Monitoring.....	30
Exporting Reports.....	31



Downloading

1. Go to http://www.zkteco.com/product/ZKBioSecurity3.0_421.html
2. Download the latest software and related files as required.




3. Once downloaded, extract the .rar file to a new folder.

4. Click on setup to begin installation.



Installation


1. System will check the requirements to install the software. Click *Continue* if all tests are passed, else check the issues and re-test.




2. Add an open port (Default 8088) or ask a network administrator for an open port.
Note: Stalone device doesn't support https.
3. Click the check box to add firewall exception for this port.

Installation

4. Select the mode of database. The default will be PostgreSQL, if you want to select any other database, then select *Alternative database*.




5. Click Browse and choose or create a folder to store your backup files.
6. Select/Create the required folder.
7. Click OK.




Adding Device


1. Click on *Access* to get below interface of Access Module of the software.



2. Click on *Device*.
3. Click on *Search Device*.




4. Click *Search* to search all the standalone devices on the network.
5. From the list, click *Add* to add the required device.





Adding Device

6. Enter a unique name.
7. Enter the IP address of current system (PC).
8. Enter the access point of system.
9. Click on this option, after adding device, the system will clear all data in the device (except the event logs).
10. Click OK to finish.

The default IP address may conflict with the device IP of other devices. In order to avoid that problem, modify the IP address as shown below:




When the device is not in the same network with server, customers should download the tool and search the device as shown below:




Creating a Time Zone

Click Access Control > Time Zones > Add to access the time zone setting interface.




After setting the time zone, click *OK* to save, and the time zone will appear in the list.





Creating an Access Level


1. Click Access
2. Click Access Control
3. Click Access Levels
4. Click New.



5. Enter the details and click *OK*.
6. You need to add doors to the access levels.




7. Select the required door(s).
8. Move the selected door(s).
9. Click *OK* to finish adding doors.



Enrolling Personnel

1. Click Personnel
2. Click Person
3. Click New to add personnel.



The 'New' form contains the following fields and options:


- Personnel ID***: 2 (Callout A)
- Department***: Marketing Department (Callout B)
- First Name**: abc
- Last Name**: xyz (Callout C)
- Gender**: Male
- Password**: [Empty]
- Social Security Number**: [Empty]
- License Plate**: [Empty]
- Reservation Code**: 123456
- Mobile Phone**: 7154879887
- Birthdate**: [Empty]
- Fingerprint**: Register (Callout F), Download New, Driver
- Finger Vein**: Register (Callout F), Download New, Card Number
- Image**: [Silhouette] (Callout D), Optimal Size 120*140, Remove, Capture
- Access Control**: Levels Settings (Callout E), Master (checked), Add, Check All, Clear All
- Personnel Detail**: Superuser (No), Device Operation Role (Ordinary User), Delay Passage, Disabled, Set Valid Time

Buttons at the bottom: Save and New, OK, Cancel.

A. Personnel ID: It must be a unique 9 characters length with the valid range of 1-79999999. It can be configured based on actual conditions. The Personnel No. contains only numbers by default but may also include letters after setting parameters.

Enrolling Personnel


- B. Department:** Select from the pull-down menu and click *OK*. If the department was not set previously, you can only select the default [Company Name] department.
- C. Password:** Set personnel password. It only supports 6-digit passwords. If password exceeds the specified length, the system will truncate it automatically. It can't be same with duress or other passwords.
- D. Card Number:** You can add a card number through manual entry or a card issuer. For issuing through issuer, click on the card icon directly. For issuing card manually, you must enter both the card number and the site code, then the software converts the numbers to the card number for access control system verification.
- E. Access Control:** Here you will get all the access levels created by you and by default. Tick the required box.
- F. Fingerprint:** Enroll the Personnel Fingerprint or Duress Fingerprint. Duress Fingerprint is to trigger the alarm and send the signal to the system in case of emergency.




Wiegand Format

Wiegand Format is the card format that can be identified by Wiegand reader. The software is embedded with 10 Wiegand formats. You may set the Wiegand card format as required.

1. Click Personnel
2. Click Card Management
3. Click Wiegand Format.
4. Taking Wiegand Format34 as an example. Click to edit.




This software supports two modes for adding Wiegand Format, if mode 1 does not meet your setting requirement, switch to mode 2.



p indicates Parity Position, s indicates Site Code, c indicates Cardholder ID, f indicates Facility Code, m indicates Manufactory Code, e indicates Even Parity, O indicates Odd Parity, b indicates both odd check and even check, x indicates parity bits no check.


Add & Delete Personnel to Access Level

1. Click Access 2. Access Control 3. Set Access by Person 4. Click on the required employee 5. Click Add to Levels.



6. Select Level(s).


7. Click to move the selected level(s) to the right, and then click OK to complete adding. The added level(s) will appear in the list on to the right side.



Real-Time Monitoring

1. Click Access
2. Click Access Device
3. Click Real-Time Monitoring

Real-time monitor the status and real-time events of standalone in the system, including normal events and abnormal events (including alarm events) device transactions.



You can also filter by Area, device name, Serial number to check a specific device transactions or all at once.

Hover over a door icon to open pop up menu as shown below and click Remote Closing, Remote Opening, or Cancel Alarm and more.

Status

Device: 192.168.1.217
 Serial Number: OIN6110016102200203
 Number: 1
 Door Sensor: No Door Sensor
 Relay: Close
 Alarm: None

[Remote Opening](#)
[Remote Closing](#)
[Cancel Alarm](#)
[Remote Normally Open](#)
[Enable Intraday Passage Mode Time Zone](#)
[Disable Intraday Passage Mode Time Zone](#)
[Query the latest events from the door](#)

Exporting Reports

Access Module:

1. Click Access 2. Click Reports 3. Filter the data (time, Personnel ID, Device Name and more) if required and click on search 4. Click All transactions or as required.

Time	Device Name	Event Point	Event Description	Media File	Personnel ID	First Name	Last Name	Card Number	Department Name
2017-04-26 17:22:44	192.168.12.116	192.168.12.116	Disconnected						
2017-04-26 17:19:22	192.168.12.116	192.168.12.116-1	Normal Verify Open		102			2760276	General
2017-04-25 17:18:21	192.168.12.116	192.168.12.116-1	Normal Verify Open		101	test1		2363700	General
2017-04-25 17:16:30	192.168.12.116	192.168.12.116-1	Normal Verify Open		102			2760276	General
2017-04-25 17:14:16	192.168.12.116	192.168.12.116-1	Normal Verify Open		102			2760276	General
2017-04-26 17:14:16	192.168.12.116	192.168.12.116-1	Normal Verify Open		101	test1		2363700	General
2017-04-25 17:14:07	192.168.12.116	192.168.12.116-1	Normal Verify Open		102			2760276	General
2017-04-25 17:14:06	192.168.12.116	192.168.12.116-1	Normal Verify Open		101	test1		2363700	General
2017-04-25 17:13:59	192.168.12.116	192.168.12.116-1	Normal Verify Open		102			2760276	General
2017-04-25 17:13:59	192.168.12.116	192.168.12.116-1	Normal Verify Open		101	test1		2363700	General
2017-04-25 17:13:38	192.168.12.116	192.168.12.116-1	Normal Verify Open		101	test1		2363700	General
2017-04-25 17:13:24	192.168.12.116	192.168.12.116-1	Normal Verify Open		101	test1		2363700	General

5. Click on *Export* to get the list.

6. Click OK.

Personnel Module:

1. Click Personnel 2. Click Person 3. Filter the data (Department, Personnel ID, and more) if required and click on search 4. Click on Export to get the list.

Personnel ID	First Name	Last Name	Department Name	Card Number	Ringing Template Quantity	Status
102			General	2760276	0 0 0	Normal
101	test1		General	2363700	0 0 0	Normal
45	admin	admin	General	2112538	0 0 0	Normal
1	x	admin	General	8682230	0 0 0	Normal
12	admin	admin	General		0 0 0	Normal
4524	admin	admin	General		0 0 0	Normal
122455432			General		0 0 0	Normal

6 Kingsbridge Road, Suite 8
Fairfield, NJ 07004
T: +1 862 505 2101
sales@zkaccess.com
www.zkaccess.com

