HIKVISION

Face Recognition Terminal

Quick Start Guide

UD19294B-B

© 2021 Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.

This Manual is the property of Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter referred to as 'Hikvision'), and it cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of Hikvision Unless otherwise expressly stated herein, Hikvision does not make any warranties, guarantees representations, express or implied, regarding to the Manual, any information contained herein About this Manual.

representations, express or implied, regarding to the Manual, any information contained referent. About this Manual
The Manual includes instructions for using and managing the Product. Pictures, charts, images and
all other information hereinafter are for description and explanation only. The information contained
in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please
find the latest version of this Manual at the Hikwision website (https://www.hikwision.com/).
Please use this Manual with the guidance and assistance of professionals trained in supporting the
Droduct

Product. Trademarks Acknowledgement HIKVISION and other Hikvision's trademarks and logos are the properties of Hikvision in various

rademarks and logos mentioned are the properties of their respective owners.

Unidictions.

Other trademarks and logos mentioned are the properties of their respective owners.

LEGAL DISSAMIMER.

EACH DISSAMIMER.

EA

PREVAILS.

Data Protection

During the use of device, personal data will be collected, stored and processed. To protect data, the development of Hikvision devices incorporates privacy by design principles. For example, for device with facial recognition features, biometrics data is stored in your device with encryption method; for fingerprint device, only fingerprint template will be saved, which is impossible to reconstruct a fingerprint image.


As data controller, you are advised to collect, store, process and transfer data in accordance with the applicable data protection laws and regulations, including without limitation, conducting security controls to safeguard personal data, such as, implementing reasonable administrative and physical security controls, conduct periodic reviews and assessments of the effectiveness of your security controls.

Scan the QR code to get the user manual for detailed information Note that mobile data charges may apply if Wi-Fi is unavailable.



Use only power supplies listed in the user instructions:

Model	Manufacturer	Standar
C2000IC12.0-24P-DE	MOSO Power Supply Technology Co., Ltd.	CEE
C2000IC12.0-24P-GB	MOSO Power Supply Technology Co., Ltd.	BS
KPL-040F-VI	Channel Well Technology Co., Ltd.	CEE



2 Installation

Installation Environment:

• Avoid backlight, direct sunlight, and indirect sunlight. · For better recognition, there should be light source in or near





Temperature Measurement Environment:

- Sunlight, wind, hot/cool air from air conditioner and other external factors, which may affect surface temperature, will create the deviation of the temperature measurement. In order to get an accurate result, make sure the device is applied indoors and windlessly (where is relatively isolated from the outdoors). The working temperature should keep between 10 °C and 35 °C. If there are no suitable environments for temperature measurement (the area faces the indoor and connects the outdoor, the area at the door of the indoor environment, etc.), building
- a temporary temperature measurement environment is suggested.

 Influence Factors of Temperature Measurement:

 Wind: The wind will take the heat away, which may affect the measurement result.

 Sweat: The sweat will take the heat away, which may affect the

measurement result.

Air Conditioner (Cool Air): If the indoor temperature is low, the surface


temperature may also lower than the actual temperature, which may affect the measurement result. Air Conditioner (Heat) or Heating: If the indoor temperature is high, the surface temperature may also higher than the actual temperature, which may affect the measurement result.


 In order to make the device work properly, you should wait for 90 min after the device is powered on.

Moutning with Bracket

Before you start:

- 1. Use 4 screws (M3 or M4), secured by flange nuts, to install the reinforcing board on the inner surface of the turnstile.
- The distance between the turnstile and the edge should be no longer than 10 mm.
- 2. Drill holes on the turnstile's inner surface according to the figure displayed below. And install water-proof nut.
- Solder after pressing rivets to avoid water from







• Rotate to open the lower cover.

Steps:

- 2 Route the cables through the cable hole on the turnstile. Align the holes on the base with those on the turnstile and place the device with bracket on the tunstile. Use 4 screws to secure the bracket and the turnstile.
- 3 Cover the lower cover on the base and rotate to secure.
- 4 Loosen the screws inside and adjust the device elevation. After adjustment, secure the screws and install the upper
- The default elevation angle is 15°. The adjustable elevation angle is from 0° to 15°.



3.2 Device Wiring (With Secure Door Control Unit)



4 Activation

Power on and wire the network cable after installation. You should activate the device before the first login

If the device is not activated yet, it will enter the Activate Device page after powering on.

- 1. Create a password and confirm the password.
- 2. Tap Activate to activate the device.
- i For other activation methods, see the device user manual.



STRONG PASSWORD RECOMMENDED-

We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

5 Temperature Measurement Settings

- 1 Hold the screen surface for 3 s and slide to right/left and verify the identity to enter the main page.
- 2. Tap "Temperature" to enter the Temperature Settings page. Configure the parameters.

Enable Temperature Detection:

When enabling the function, the device will authenticate the permissions and at the same time take the tempearture. When disabling the device, the device will authenticate the permissions only.

Over-Temperature Alarm Threshold:

Edit the threshold according to actual situation. If the detected temperature is higher than the configured one, an alarm will be triggered. By default, the value is 37.3°.

Temperature Compensation:

If the measured temperature is higher/lower than the actual object's temperature, you can set the compensation temperature here. Available range: -99 °C to 99 °C.

Door Not Open When Detecting Abnormal Termperature:

When Enabling the function, the door will not open when the detected temperature is higher than the configured temperature threshold. By default, the temperature is enabled.

Temperature Measurement Only:

When enabling the function, the device will not authenticate the permissions, but only take the temperature. When disabling the function, the device will authenticate the permsissions and at the same time take the temperature.

Positions When Collecting/

Comparing Face Picture

(Recommended Distance: 0.5m)

Unit: Select a temperature unit according to your preference.

Regulatory Information

Please take attention that changes or modification not expressly approved by the party responsible for liance could void the user's authority to operate the equipment.

FCC compliance: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

—Regrient or relocate the receiving antenna

Increase the separation between the equipment and receiver

—Connect the equipment into an outlet on a circuit different from that to which the receiver is

-Consult the dealer or an experienced radio/TV technician for help.

This equipment should be installed and operated with a minimum distance 20cm between the radiator and your body

FCC Conditions

his device complies with part 15 of the FCC Rules. Operation is subject to the following two

1. This device may not cause harmful interference

2. This device must accept any interference received, including interference that may cause undesired



This product and - if applicable - the supplied accessories too are marked with "CE" and comply therefore with the applicable harmonized European standards listed under the RE Directive 2014/53/EU, the EMC Directive 2014/30/EU, the RoHS Directive 2011/65/EU

2006/66/EC (battery directive): This product contains a battery that cannot be

disposed of as unsorted municipal waste in the European Union. See the



product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplie or to a designated collection point. For more information see: www.recycle-2012/19/EU (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper

recycling, return this product to your local supplier upon the purchase of



equivalent new equipment, or dispose of it at designated collection points. For more information see: www.recvclethis.info COMPLIANCE NOTICE: The thermal series products might be subject to export controls in various

countries or regions, including without limitation, the United States, European Union, United Kingdom and/or other member countries of the Wassenaar Arrangement. Please consult your professional legal or compliance expert or local government authorities for any necessary export license requirements if you intend to transfer, export, re-export the thermal series products between different countries.

Safety Instruction

These instructions are intended to ensure that user can use the product correctly to avoid danger or

The precaution measure is divided into Warnings and Cautions:

Warnings: Neglecting any of the warnings may cause serious injury or death.
Cautions: Neglecting any of the cautions may cause injury or equipment damage.

Warnings All the electronic operation should be strictly compliance with the electrical safety regulations, fire prevention regulations and other related regulations in your local region.

 Please use the power adapter, which is provided by normal company. The power consumption cannot be less than the required value.

Do not connect several devices to one power adapter as adapter overload may cause over-heat or

• Please make sure that the power has been disconnected before you wire, install or dismantle the

When the product is installed on wall or ceiling, the device shall be firmly fixed. • If smoke, odors or noise rise from the device, turn off the power at once and unplug the power

cable, and then please contact the service center. • If the product does not work properly, please contact your dealer or the nearest service center.

Never attempt to disassemble the device yourself. (We shall not assume any responsibility for problems caused by unauthorized repair or maintenance.)

(1) Cautions

• Do not drop the device or subject it to physical shock, and do not expose it to high electromag netism radiation. Avoid the equipment installation on vibrations surface or places subject to shock (ignorance can cause equipment damage).

• Do not place the device in extremely hot (refer to the specification of the device for the detailed

operating temperature), cold, dusty or damp locations, and do not expose it to high electromagnetic

The device cover for indoor use shall be kept from rain and moisture.

● Exposing the equipment to direct sun light, low ventilation or heat source such as heater or radiator is forbidden (ignorance can cause fire danger)

● Do not aim the device at the sun or extra bright places. A blooming or smear may occur otherwise which is not a malfunction however), and affecting the endurance of sensor at the same time

• Please use the provided glove when open up the device cover, avoid direct contact with the device cover, because the acidic sweat of the fingers may erode the surface coating of the device cover.

• Please use a soft and dry cloth when clean inside and outside surfaces of the device cover, do not use alkaline detergents.

 Please keep all wrappers after unpack them for future use. In case of any failure occurred, you need to return the device to the factory with the original wrapper. Transportation without the original wrapper may result in damage on the device and lead to additional costs. • Improper use or replacement of the battery may result in hazard of explosion. Replace with the

same or equivalent type only. Dispose of used batteries according to the instructions provided by the battery manufacturer.

Biometric recognition products are not 100% applicable to anti-spoofing environments. If you

require a higher security level, use multiple authentication modes.

• Indoor use. If installing the device indoors, the device should be at least 2 meters away from the

light, and at least 3 meters away from the window or the door. Input voltage should meet both the SFLV (Safety Extra Low Voltage) and the Limited Power Source with 100~240 VAC or 12 VDC according to the IEC60950-1 standard. Please refer to technical specifications for detailed information.

Tips When Collecting/ Comparing Face Picture

Expression

- Keep your expression naturally when collecting or comparing face pictures, just like the expression in the picture on the right.
- Do not wear hat, sunglasses, or other accessories that can affect the facial recognition function.
- Do not make your hair cover your eyes, ears, etc. and heavy makeup is not allowed.

Posture

In order to get a good quality and accurate face picture, position your face looking at the camera when collecting or comparing face pictures.











Make sure your face is in the middle of the collecting window.





















1. Hold the screen surface for 3 s and slide to right/left and verify the identity to enter the main page

- 2. Enter the User Management page, tap + to enter the Add User
- 3. Set the user parameters according to actual needs.
- 4. Tap Face add the face information according to the instruc-You can view the captured picture on the screen.

Make sure the face picture is in good quality and size. For details about the tips and positions when collecting or

face picture, see the contents on the right.

- 5. If the picture is in good condition, tap Or tap o to take another face picture.
- 6. Tap the save icon to save the settings. Go back to the initial page to start authentication. For other authentication methods, see the device user manual.
- Use other authentication methods if the device is affected by the light or other items.



Biometric recognition products are not 100% applicable to anti-spoofing environments. If you require a higher security level, use multiple authentication modes. `~------