
4 Ports PoE Ethernet Switch User Manual

4 ports PoE Ethernet Switch is a surveillance security Ethernet Switch which aims at Ethernet high definition surveillance, Ethernet project security system. The product fully combines the characteristic of surveillance security, provides fast packet forwarding ability and abundant backplane bandwidth, which ensures clear image and fluent transmission. ESD and surge protection circuit can improve product stability. The product supports one key CCTV model, can achieve VLAN, control the Net storm, protect the information security, prevent the viral transmission and Ethernet attack, fully satisfy the Ethernet video surveillance security system and Ethernet project needs.



Feature

- Major ports: 1 pcs 100Mbps uplink optical port, 4 pcs 100Mbps down link Ethernet ports, every port supports MDI/MDIX;
- Special function: One key CCTV model; 1 ~ 4 downlink ports can only communicate with uplink ports;
- Power input: DC48V ~ 57V;
- Transmission Distance : Ethernet port 0 ~ 100m, the furthest transmission distance could reach 250m in CCTV model; Optical port 20km;
- Standard: Meet IEEE802.3 ,IEEE802.3u,IEEE802.3 af/at standards, PoE use End-Span, the spare cable can be of other use;
- Protection: Excellent anti-thunder, anti-static and anti-interference ability;
- Appearance: Delicate design and easy installation, configure the anti-theft lock hole, guard against theft;
- Operation: Plug and Play, No Setting required.

<u>||</u> Notice


The transmission distance is related to the connected cable. We suggest standard

Cat5e/6 network cable, so the transmission distance can up to furthest!


Board Diagram

Front board

VerB 1.3



Back board



1) Device must be connected with lightning protection grounding; otherwise protection level will reduce; please use above No.20 wire to connect the grounding terminal.

2) Turn the dial switch for left, the equipment can enter surveillance mode after providing equipment power.

Installation steps

Please check the following items before installation, if it is missing, please contact the dealer.

•	4 ports PoE Ethernet Switch	1pc
•	Power adaptor	1pc
•	AC power cable	1pc
•	Accessory	1pc
•	User manual	1pc

Please follow the below installation steps

1) Please turn off the signal power and display device power before installation, installation with power will damage the transmission equipment;

2) Use network cable connect PoE IP camera and 1~4 downlink ports of product respectively;

- 3) Use fiber connect equipment uplink optical port and uplink equipment' s(optical converter) optical port, please notice that the fiber port RX and TX need cross-linking.
- 4) Connect power adapter;
- 5) Check if the installation is correct, equipment is in good condition, the connection is stable, then provide power for system;
- 6) Ensure the Ethernet equipment with power and work properly.

Specification

	Item		Des	cription		
	Power Supply		Powe	r Adaptor		
Power	Voltage Range	DC48V~54V				
	Consumption			<5W		
Ethernet	Speed	1-4 port:Default:10/100Mbps; CCTV:10Mbps; UPLINK:100Mbps				
Linomot	Transmission Distance	1-4 port:Default:0~100m; CCTV:0~250m; UPLINK:20Km				
	Ethenet Standard	IEEE 802.3/802.3u/802.3af/at				
	Exchange Capacity		1.	0Gbps		
Network Switch	Packet Forwarding Rate		0.7	'4Mpps		
Network Switch	Packet Buffer	768K				
	MAC			2K		
	Power Light		1p	c(Red)		
Status Indicator	Ethernet Port Light	2pcs(Yellow&Green) on RJ45,yellow indicates PoE, green indicates Link/Act				
	Optical Light	1pc(green), green indicates Link/Act				
	Surveillance Module Light	1pc(Green), green indicates CCTV				
	Pluse Group	Level 3 Standard: IEC61000-4-4				
Protection Level	ESD	1a Contact Discharge Level 3 1b Air Discharge Level 3 Standard: IEC61000-4-2				
	Anti-thunder Level	6KV Standard: IEC61000-4-5				
) Marking	Working Temperature		-10	°C~55°C		
Working Environment	Storage Temperature	−40℃~85℃				
Linvironment	Humidity(Non-condesing)	0~95%				
	Dimension(L*W*H)		135mm×8	5.6mm×27mm		
	Out Shell	Galvanized Sheet				
Mechanical	Color	Black				
	Weight	315g				
Power/Distance	Distance	100m	150m	200m	250m	
54V	Power	26W	24W	23W	21W	

Specification change will not be noticed

Trouble Shooting

Please follow the steps if the equipment has trouble.

- Make sure the equipment is installed according to the manufactures installation guide.
- Confirm RJ45 cable order meets EIA/TIA568A or 568B standard.
- Every PoE port can provide PoE equipment maximum power less than 30W, please do not connect the PoE equipment with power over 30W.
- Replace the equipment with a proper functioning 4 ports PoE Ethernet Switch to check if the equipment is damaged.
- Please contact your vendor if trouble still exists.

Plug Producing Method

Instruments to be used: wire crimper, network tester. Wire sequence of RJ45 plug should conform with EIA/TIA568A or 568B.

1) Please remove 2cm long the insulating layer, and bare 4 pairs UTP cable;

2) Separate the 4 pairs UTP cable and straighten them;

3) Line up the 8 pieces of cables per EIA/TIA 568A or 568B;

4) Cut off the cables to leave 1.5cm bare wire;


5) Plug 8 cables into RJ45 plug, make sure each cable is in each pin;

6) Use the wire crimper to crimp it;

7) Repeat above 5 steps to make the another end;

8) Use network tester to test the cable if it works.

Pin	Color
1	White/Green
2	Green
3	White/Orange
4	Blue
5	White/Blue
6	Orange
7	White/Brown
8	Brown



EIA/TIA 568A

EIA/TIA 568B

🚺 Notice

When choose RJ45 make sure if one end is EIA/TIA568A, the other end should also be EIA/TIA568A. When choose RJ45 make sure if one end is EIA/TIA568B, the other end should also be EIA/TIA568B.